


LYSAGHT
LIMITED



Check List for Horse Floats

- Walk around float, checking tyres, hand brake, mudguards.
- **Check all doors are securely fastened.**
- 50mm tow ball is recommended (new multi-size connection check ball size).
- Coupling handle must clip down into place and on correct side (ball size).
- Keep reversing clip down when backing.
- Tie ratchet back (to avoid handbrake coming on accidentally) – Hand brake for hills only.
- Hand brake must not be left on for long periods
- Tyre of jockey wheel up when travelling.
- Test lights after plugging in.
- Grease nipple and suspension slides every year.
- Check brake fluid and tyre pressure every six months (minimum of 50psi) also wheel nuts.
- For ease of washing a good polish from new is advised.
- Keep coupling etc covered with a sack not plastic when parked up.
- Avoid water penetration around slave cylinder on coupling.
- Tie horse to side with non synthetic twine.

~ REMEMBER TO DRIVE AS IF YOU HAVE A BUCKET ON WATER BESIDE YOU ~

Do you have a horse that does not float well?

Try one of our Lysaght Ltd Angle Loaders 😊